

Punch Break Out

Punch flare out will be start aproximatly @ the mid point of the flat and will flare out to $\sim 12\%$ of the flat thickness + the desire features size

(This holds true for all shapes of punched holes)

