

Wings

- ▲ Thickness and width of wing work hand in hand
- ▲ More Thickness = Less Width
- ▲ Less Thickness = More Width
- ▲ Center of wing/stake typically will be on outside edge of wire.
- ▲ Wing dimensions can be to the center of the wing, but for function should be dimensioned to the edges of the wing
- ▲ Wings typically are centered on the wire (see front view)
- ▲ Radial wing location to be held ± 5 degrees

